

Via Enzo Ferrari, 39 Zona Industriale D3 15121 Alessandria, Italy



TECHINICAL SPECIFICATIONS

Vitop Easy Connector

The Easy Connector is especially adapted to dispensers of sensitive products that require perfect hygiene. It is perfectly compatible with the Original Vitop standard tap. The dispenser must be equipped with a pump. The connector doesn't work using just gravity flow.

It is extremely easy to disassemble and doesn't use a spring, making cleaning even easier (see Annex I, Use Instructions).

The Easy Connector is apt for contact with food liquids. Various end-fittings are available: 6 mm and 10 mm diameters.



• Composition

Vitop Easy Connector is made of six components, materials used are reported in the following table:

Component	Material	Masterbatch
Spring	Stainless steel	N.A.
Top Button	Polypropylene (PP)	YES
Body	Polypropylene (PP)	YES
Lever	Polypropylene (PP)	YES
End fitting	Polypropylene (PP)	YES
Valve	Silicon	N.A.



Via Enzo Ferrari, 39 Zona Industriale D3 15121 Alessandria, Italia SP F CN E 013 Edition: 00 Revision: 00 Date: 28/07/2016

• Storage specification and shelf-life of Easy Vitop Connectors

Vitop Easy Connectors are adequately packed and sent to the customer on cardboard boxes with protective adhesive tape (quality seal).

The temperature of the zone where Vitop Easy Connectors are stocked shall be over 4°C and less than 30°C.

The period between delivery of the Vitop Easy Connectors by Vitop and their use by the final consumer must not exceed two and half years.

Vitop suggests to use FIFO for stock management.

• Food contact and others statements

Vitop Easy Connector meets EU and FDA food contact requirements. Specific statements for food contact, as well as for REACH, heavy metals and the environment, are provided by Vitop on request.

• Reference certification

Vitop has adopted an appropriate Quality System and internal procedures certified by:

0	UNI EN ISO 9001:2008	(quality management systems)

• UNI EN ISO 22000:2005 (food safety management)

The entire Vitop production plant is kept very clean, meeting the rigorous requirements for packaging materials intended to come into contact with food. Our HACCP plan aims to minimize the risk of contamination of food-packaging materials with pathogens or foreign substances.

• Responsibility

The information provided above is supplied in good faith and it does not comprise a guarantee or warranty of any kind either expressed or implied. This data should be considered as average typical properties observed rather than a guaranteed specification. It is the customer's responsibility to test the suitability of these products for its specific application. Vitop cannot be considered responsible for any improper use of its products by the buyer and/or the final consumer and assumes no liability for any incidents that may arise from the use of this data. As the regulations and products mentioned in this statement change over time, Vitop advises its customers to ask for a new declaration periodically. Food contact compliance letters are available upon request. It is the responsibility of the end user to assure compliance with any packaging regulations applicable to the end use for which the product is manufactured.

This declaration cancels any previous version.



Via Enzo Ferrari, 39 Zona Industriale D3 15121 Alessandria, Italia SP F CN E 013 Edition: 00 Revision: 00 Date: 28/07/2016

• Annex I – Use Instructions

Connecting the Vitop Easy Connector



Place the tap inside the connector



Push (pivot) to close the connector



Screw the red top button

Disconnecting the Vitop Easy Connector







Open the connector

Pull (pivot) to open the connector

Remove the tap

Dismantling the Vitop Easy Connector



Reassembling the Vitop Easy Connector



Replace the valve into the end fitting



Assemble the connector



Screw on the end fitting